


- - 3.1 Turn the dials to the set code, e.g. 8-8-8-8
 - 3.2 Rotate the knob to CLOSE position.
 - 3.3 Turn the dials to any number for locking.
- 4. In order to UNLOCK.
 - 4.1 Turn the dials to the previously set secret code, e.g. 8-8-8-8.
 - 4.2 Rotate the knob to OPEN position.


TO RECOVER THE SECRET CODE COMBI - PRIVATE (No. 821)

WHEN THE LOCK IS IN OPEN POSITION




2.Turn each of the dials until it cannot move (all four dials)—to recover the forgotten secret code. 3.Pull the special tool out of the slot. The lock

can now be used normally



- and rotate it clockwise until stop.
- 2.Turn each of the dials until it cannot move (all four dials)—to recover the forgotten secret code 3.Rotate the key counter-clockwise until stop and pull the key out. The lock can now be used normally.


OPERATING INSTRUCTIONS COMBI - PUBLIC (No. 822)



- 1. The preset factory code is 0-0-0-0.
- 2.To change the secret code,

то


- 2.1 Rotate the knob to OPEN position.
- 2.2 The new secret code can be reset, e.g. 8-8-8. The process is complete.



- 3.In order to LOCK.
 - 3.1 Rotate the knob to CLOSE position.
- 3.2 Turn the dials to any number for locking. 4.In order to UNLOCK.
 - 4.1 Turn the dials to the previously set secret code, e.g. 8-8-8.
 - 4.2 Rotate the knob to OPEN position.

Remarks: The secret code for COMBI-PUBLIC can be reset when the lock is in OPEN position.






- 1.Insert the key into the RECOVERY KEY SLOT and rotate it clockwise until stop.
- 2.Turn each of the dials until it cannot move (all four dials)—to recover the forgotten secret code. 3. Rotate the key in counter-clockwise until stop

and pull the key out. The lock can now be used normally.









FROM COMBI - PUBLIC (No. 822) COMBI - PRIVATE (No. 821)






- 1.The lock is in OPEN position.
- 2.Slide the FUNCTION SWAP BUTTON to 2.PUBLIC to change the function to COMBI-PUBLIC.

Remarks: For Step 2, remove the cam should it obstruct the FUNCTION SWAP BUTTON. 15



- 1.The lock is in OPEN position.
- 2. The secret code can be reset right away, e.g. 8-8-8-8.
- 3.Rotate the knob to CLOSE position.





- 4.Slide the FUNCTION SWAP BUTTON to 1.PRIVATE
- 5.Rotate the knob to OPEN position to change the function to COMBI-PRIVATE.

Remarks: For Step4, remove the cam should it obstruct the FUNCTION SWAP BUTTON.

